

BQ FibreLine Flat Sheet Panel - Installation Guide



Demo Installation Guide – Demonstration only.

Components: FibreLine Flat Sheet Panels, FC Nails, Joint Sealant, Cut End Sealer and Aluminium Joiner Beads.

Installation Sequence: Install horizontal battens, treat all cut edges, fit joiner beads, install panels vertically, maintain consistent joints, seal where specified and apply finish coat.

Inspection: Check alignment, fixings, panel joints and flashings before painting.

Always refer to the official manufacturer installation guide for complete requirements.