

BQ FibreLine Soffit Sheet Installation Guide (Demo)



Product

BQ FibreLine Soffit Sheet is a pre-primed fibre cement lining sheet for eaves, soffits, verandahs, alfresco ceilings and carports. Available in Smooth and Perforated ventilation profiles.

Components

- BQ FibreLine Soffit Sheet (Smooth or Perforated)
- BQ FibreLine FC Nails 30 x 2.8mm
- BQ FibreLine FC Joint Sealant
- BQ FibreLine Cut End Sealer

Installation

1. Ensure framing is straight, dry and correctly spaced.
2. Measure and cut sheets as required.
3. Apply Cut End Sealer to all field-cut edges.
4. Position sheets with joints supported by framing.
5. Fix using FC Nails at recommended centres.
6. Seal joints and penetrations with FC Joint Sealant where required.
7. Prime (if required) and apply exterior paint system after installation.

Applications

Residential eaves, verandahs, alfresco ceilings, carports and covered outdoor ceilings.

Important

This is a demonstration document only. Always follow the official manufacturer installation instructions and relevant Australian Standards.