

INSTALLATION GUIDE

BQ FibreLine VGroove Panel

Quick reference installation summary for pre-primed fibre cement VGroove cladding panels. This is a BuildQuote demo guide only.



Before you start

Confirm framing, wind classification, wall wrap, flashing strategy, panel set-out and finish colour before installation. Store panels flat, dry and protected from weather.

System components

VGroove panels, FC nails, joint sealant, cut end sealer and aluminium jointer bead. Seal all cut edges before fixing.

Installation Sequence

Step	Action
1	Set out horizontal batten framing and confirm fixing centres against project requirements.
2	Install wall wrap, flashings and cavity detailing as required by the project documentation.
3	Pre-seal all cut edges with BQ FibreLine Cut End Sealer before panel installation.
4	Fix panels vertically to horizontal battens using approved fibre cement nails. Keep sheets plumb and aligned.
5	Use aluminium jointer bead and flexible joint sealant at panel junctions, penetrations and terminations.
6	Complete final paint system to coating supplier requirements after inspection and make-good.

Product + Accessory Codes

Item	Code
VGroove Panel 133mm	BQ-FL-VGP-133-2400
VGroove Panel 200mm	BQ-FL-VGP-200-2400
FC Nail 30mm x 2.8mm 1kg	BQ-FL-NAIL-30MM-1KG
FC Joint Sealant 300mL	BQ-FL-SEALANT-300ML
Cut End Sealer 250mL	BQ-FL-ENDSEAL-250ML
Aluminium Jointer Bead 3000mm	BQ-FL-JOINTER-AL-3000

Important: This quick reference is not a full installation manual. Always use the official manufacturer installation guide for wall wrap, flashing, cavity, fixing centre, fire and warranty requirements.