

BQ FibreLine Weatherboard Plank - Installation Guide



Demo Installation Guide – Demonstration only.

Components: Weatherboard Planks, FC Nails, Joint Sealant, Cut End Sealer and Aluminium Starter Track.

Installation: Install wall wrap and battens, fix starter track level, seal cut edges, install planks from bottom upwards with consistent overlap, nail to framing, seal penetrations and joints where required.

Finish: Inspect alignment, apply site paint and complete final clean.

Always refer to the official manufacturer installation guide before construction.