

BQ INFORM

BQ InForm VJ Lining System

BQ-IN-VJ

PRODUCT SNAPSHOT

Demo tongue-and-groove MDF VJ lining sheet for internal walls and ceilings. Available primed or factory-finished. Designed to be fixed to timber or steel framing with adhesive plus mechanical fixings.

SUITABLE FOR

- ✓ Internal dry-area walls and ceilings
- ✓ Timber or steel framing
- ✓ Residential renovations and new builds
- ✓ Painted interior feature lining

BEFORE YOU START

Check substrate

Framing must be straight, dry, plumb and ready for lining.

Condition sheets

Store flat and allow sheets to acclimatise to internal site conditions.

Confirm set-out

Plan visible joints, corners, trims, windows, doors and ceiling junctions before fixing.

QUICK INSTALLATION SEQUENCE

1

Prepare the frame

Confirm stud spacing, noggins, services and insulation are complete. Remove dust and moisture from fixing faces.

2

Set out the first sheet

Start from a square corner or main sightline. Allow movement at floor, ceiling and junctions.

3

Apply adhesive

Apply adhesive to framing members in continuous beads. Avoid squeeze-out.

4

Fix the sheet

Place sheet firmly. Secret nail through tongue where practical, or face fix neatly.

5

Continue lining

Engage joints fully. Check alignment often and keep joint faces clean.

6

Finish with trims

Install cornice, joining strips and trims. Fill, sand and paint primed sheets.

SYSTEM COMPONENTS

ITEM	CODE	UNIT	USE
VJ Lining Sheet 2400 x 900 x 9mm	BQ-IN-VJ-2400-900	Sheet	Main wall or ceiling lining
VJ Lining Sheet 2700 x 900 x 9mm	BQ-IN-VJ-2700-900	Sheet	Main wall or ceiling lining
VJ Lining Sheet 3000 x 900 x 9mm	BQ-IN-VJ-3000-900	Sheet	Main wall or ceiling lining
Cove Cornice 90 x 3600mm	BQ-IN-CORNICE-90-3600	Length	Wall to ceiling finish
Window & Door Trim 55 x 3600mm	BQ-IN-WINTRIM-55-3600	Length	Openings and edges
VJ Joining Strip 3600mm	BQ-IN-JOINSTRIP-3600	Length	Butt joins and internal wall joins
Construction Adhesive 450mL	BQ-IN-ADHESIVE-450ML	Box	Bond sheets and trims to framing
Lost-Head Nail 50mm 1kg	BQ-IN-NAIL-50MM-1KG	Bag	Secret nailing or neat face fixing

GOOD SITE PRACTICE

- ✓ Keep sheets dry before installation
- ✓ Support all sheet edges and joins
- ✓ Fix to every required framing member
- ✓ Prime cut edges where painting system requires
- ✓ Use trims to control visible junctions

AVOID

- ✗ Installing onto damp or twisted framing
- ✗ Forcing sheets out of square
- ✗ Over-driving nails or screws
- ✗ Unsupported butt joints
- ✗ Using this guide as a compliance certificate

DEMO GUIDE NOTE

This PDF is a BuildQuote demonstration asset for the fictional BQ InForm product shown in the demo System Card flow. It is not a manufacturer technical manual, warranty document, compliance certificate or substitute for project-specific building advice.

OPEN IN BUILDQUOTE



System Card:
BQ InForm VJ Lining System

Domain:
search.buildquote.com.au

Australian Made

Pre-primed / site painted

Interior dry areas

Timber or steel frame